

SIMATIC RF600 Starter package Basic 1x RF650R ETSI reader 2x RF650A antennas 1x wide-range power supply unit 1 x power supply unit cable 24 V, 5 m 2x antenna cable, 5 m 1x RJ45 Ethernet cable, 6 m 1x power cable for power supply (EU) 20x transponder RF645T 20x fastening hood for RF645T 3x mounting kits for reader/ant.



Figure similar